

## Návod na inštaláciu


Stropné svietidlo:

ACLO33NW-18W  
ACLO33NW-18W-ALU  
ACLO33NW-18W-ME  
ACLO33NW-18W-MO  
ACLO33NW-18W-RD  
ACLO33NW-18W-S  
ACLO33NW-18W-HL-ST  
ACLO33NW-18W-LAR

ACLOCCT-48W-R-ALU  
ACLOCCT-48W-R-ST  
ACLOCCT-80W-R-ST  
ACLO38NW-24W-LAR  
ACLO38NW-24W  
ACLO38NW-24W-ALU  
ACLO38NW-24W-HL-ST

avide 

ACLO28NW-12W  
ACLO28NW-S-12W



Distribútor:

**Vario**  
TRADE

Vario Trade, s. r. o.  
T. Vansovej 1750/2  
979 01 Rimavská Sobota

## Návod na inštaláciu


Stropné svietidlo:

ACLO33NW-18W  
ACLO33NW-18W-ALU  
ACLO33NW-18W-ME  
ACLO33NW-18W-MO  
ACLO33NW-18W-RD  
ACLO33NW-18W-S  
ACLO33NW-18W-HL-ST  
ACLO33NW-18W-LAR

ACLOCCT-48W-R-ALU  
ACLOCCT-48W-R-ST  
ACLOCCT-80W-R-ST  
ACLO38NW-24W-LAR  
ACLO38NW-24W  
ACLO38NW-24W-ALU  
ACLO38NW-24W-HL-ST

avide 

ACLO28NW-12W  
ACLO28NW-S-12W



Distribútor:

**Vario**  
TRADE

Vario Trade, s. r. o.  
T. Vansovej 1750/2  
979 01 Rimavská Sobota